

	Teile-Nr.	Bestell-Nr.	Stück je Maschine		Teile-Nr.	Bestell-Nr.	Stück je Maschine
Schaftdichtung	1	P16S/1	1	Bohrkopf	42	P16S/42	1
Sicherungsfeder	2	P16S/2	1	Zylinderschraube M4x25	43	P16S/43	2
Zylinderrolle	3	P16S/3	1	Sicherungsscheibe M4	44	P16S/44	4
Werkzeughalter	4	P16S/4	1	Zylinderschraube M4x16	45	P16S/45	2
O-Ring 14x3	5	P16S/5	1	Nadelhülse	46	P16S/46	2
Futterrolle	6	P16S/6	2	Doppelabstreifer	47	P16S/47	1
Futter	7	P16S/7	1	Nadellager	48	P16S/48	1
Döpper	8	P16S/8	1	Bohrkopfdichtung	49	P16S/49	1
O-Ring 9,5x1,6	9	P16S/9	1	V-Ring	50	P16S/50	1
O-Ring 24x4	10	P16S/10	1	Rastenfeder	51	P16S/51	1
Bohrspindel	11	P16S/11	1	Kugel Ø 4mm	52	P16S/52	1
Sprengring	12	P16S/12	1	Zylindergehäuse	53	P16S/53	1
Schaltfeder	13	P16S/13	1	Linsenkopfschraube 4x14	54	P16S/54	10
Kupplungsfeder	14	P16S/14	1	Rillenkugellager	55	P16S/55	1
Haltestift	15	P16S/15	1	Luftleitflansch	56	P16S/56	1
Spindelrad	16	P16S/16	1	Motorgehäuse	57	P16S/57	1
Nadelrolle	17	P16S/17	4	DUSS-Aufkleber	58	P16S/58	2
O-Ring 38x5	18	P16S/18	1	Selbstklebeschild R-L	59	P16S/59	1
Axialscheibe	19	P16S/19	2	Typenschild	60	P16S/60	1
Axialnadelkranz	20	P16S/20	1	Kohlebürste	61	P16S/61	2
Bremsring	21	P16S/21	1	Kohlebüchse	62	P16S/62	2
Zylinderschraube M4x12	22	P16S/22	2	Sechskantmutter M5	63	P16S/63	1
Zylinder	23	P16S/23	1	Kreuzgriffschraube	64	P16S/64	1
Schläger	24	P16S/24	1	Klemmring	65	P16S/65	1
Schlägerring	25	P16S/25	1	Schraubhandgriff	66	P16S/66	1
Kolben	26	P16S/26	1	Einlegemutter M10	67	P16S/67	1
Kolbenbolzen	27	P16S/27	1	Anschlagstange	68	P16S/68	1
Stützscheibe	28	P16S/28	2	Tülle	69	P16S/69	1
Axialscheibe	29	P16S/29	4	Passscheibe	70	P16S/70	1
Axialnadelkranz	30	P16S/30	2	Anker	71	P16S/71	1
Tellerfeder	31	P16S/31	1	Linsenkopfschraube 4x48	72	P16S/72	4
Vorgelegewelle	32	P16S/32	1	Rillenkugellager	73	P16S/73	1
Sprengring	33	P16S/33	1	Feldpaket	74	P16S/74	1
Schlagtrennfeder	34	P16S/34	1	Stabkerndrossel, schwarz	75	P16S/75	1
Schaltklaue	35	P16S/35	1	Stabkerndrossel, blau	76	P16S/76	1
Rotationsschwinge	36	P16S/36	1	Umschalter	77	P16S/77	1
Ankergegenrad	37	P16S/37	1	Schalter	78	P16S/78	1
Linsensenkschraube M4x10	38	P16S/38	1	Kondensator	79	P16S/79	1
Pneumatikschale	39	P16S/39	1	Kabelschutzschlauch	80	P16S/80	1
O-Ring 5x1,5	40	P16S/40	1	Kabelklemme	81	P16S/81	1
Umschalthebel	41	P16S/41	1	Kabel mit Stecker	82	P16S/82	1

# DUSS

## Bohrhammer P 16 S

