

	Teile-Nr.	Bestell-Nr.	Stück je Maschine		Teile-Nr.	Bestell-Nr.	Stück je Maschine
Schraubhandgriff	1	P26/1	1	Anker	51	P26/51	1
Einlegemutter M10	2	P26/2	1	Rillenkugellager	52	P26/52	1
Klemmring	3	P26/3	1	Lagergummi	53	P26/53	1
Kreuzgriffschraube	4	P26/4	1	O-Ring 16x5	54	P26/54	1
Sechskantmutter M5	5	P26/5	1	Schläger	55	P26/55	1
Anschlagstange	6	P26/6	1	Kolbenring	56	P26/56	1
Tülle	7	P26/7	1	Kolbenring	56p	P26/56p	1
Schaftdichtung	8	P26/8	1	Kolbenbolzen	57	P26/57	1
Sicherungsfeder	9	P26/9	1	Federring	58	P26/58	2
Werkzeughalter	10	P26/10	1	Kolben	59	P26/59	1
O-Ring 14x3	11	P26/11	1	Pleuel	60	P26/60	1
Zylinderrolle	12	P26/12	1	Kurbel	61	P26/61	1
Futterrolle	13	P26/13	2	Rillenkugellager	62	P26/62	1
Futter	14	P26/14	1	Kurbelrad	63	P26/63	1
Zylinderschraube M5x20	15	P26/15	4	Axialscheibe	64	P26/64	1
Bohrkopf	16	P26/16	1	Linsenkopfschraube 4x48	65	P26/65	2
Bohrkopfdichtung	17	P26/17	1	Luftleitflansch	66	P26/66	1
Doppelabstreifer	18	P26/18	1	Feldpaket	67	P26/67	1
Nadellager	19	P26/19	1	Motorgehäuse	68a	P26/68a	1
Ring	20	P26/20	1	Linsenschraube 3,5x30	69	P26/69	2
O-Ring 9x3	21	P26/21	4	Umschalthebel	70	P26/70	1
Döpper	22	P26/22	1	Linsensenkschraube M4x10	71	P26/71	1
O-Ring 24x4	23	P26/23	1	Typenschild	72	P26/72	1
Quadrang	24	P26/24	1	Linsenkopfschraube 3x10	73	P26/73	4
Bohrspindel	25	P26/25	1	Kohlebürste	74	P26/74	2
Haltestift	26	P26/26	1	Kohlehalter	75	P26/75	2
Nadelrolle	27	P26/27	4	Motordeckel	76	P26/76	1
Kupplungsfeder	28	P26/28	1	DUSS-Aufkleber	77	P26/77	2
Anlaufscheibe	29	P26/29	2	Nadelhülse	78	P26/78	1
Sprengring	30	P26/30	1	Senkschraube M5x8	79	P26/79	1
Sicherungsring	31	P26/31	1	Rastenfeder	80	P26/80	1
Dämpfscheibe	32	P26/32	3	Kugel Ø 4mm	81	P26/81	1
O-Ring 35x5	33	P26/33	1	Zylindergehäuse	82	P26/82	1
Dämpfring	34	P26/34	1	Linsenkopfschraube 4x25	83	P26/83	6
Sprengring	35	P26/35	2	Schaltwelle	84	P26/84	1
Runddrahtsprengring	36	P26/36	1	O-Ring 12x1,5	85	P26/85	1
Zylinder	37	P26/37	1	Zylindergehäusedichtung	86	P26/86	1
Oberschale	38a	P26/38a	1	Kondensator	87	P26/87	1
Linsenschraube 3,5x20	39	P26/39	4	Dämpfer-Zylindergehäuse	88	P26/88	1
Kegelritzelrad	40	P26/40	1	Schalter	89	P26/89	1
Rillenkugellager	41	P26/41	1	Schalterschutz	90	P26/90	1
Zylindertager	42	P26/42	2	Dämpfer-Motorgehäuse	91	P26/91	1
Getriebeplatte	43	P26/43	1	Schalterhandgriff	92	P26/92	1
Kupferdichtring M5	44	P26/44	6	Linsenschraube 5x30	93	P26/93	4
Zylinderschraube M5x16	45	P26/45	6	Linsenkopfschraube 4x20	94	P26/94	2
V-Ring	46	P26/46	1	Abstandsbuchse	95	P26/95	4
O-Ring 18x2	47	P26/47	1	Linsenkopfschraube 4x14	96	P26/96	6
V-Ringscheibe	48	P26/48	1	Kabelklemme	97	P26/97	1
Rillenkugellager	49	P26/49	1	Kabelschuttschlauch	98	P26/98	1
Sicherungsring	50	P26/50	1	Kabel mit Stecker	99	P26/99	1

# DUSS

## Bohrhammer P 26

