



Onderdeellijsten

REFERENCE N°	DESCRIPTION
BEDPLATE UNIT	
01	Bed
02	Pump guard
03	Chip collect box
04	Hydraulic unit housing guard
05	Arm locking lever
06	Arm locking bush
07	Lever handgrip
08	Electric box
09	Electric system housing cover
10	Feed cylinder guard
11	Chute
12	Arm rotation pin
13	Counter die fastening square
14	Vertical roller
15	Revolving arm
16	Support
17	Eccentric bush
18	Bearing NKI 20/16
19	Roller
20	Support
21	Vertical roller guide
22	Vertical roller nut
23	Washer
24	Bearing 6002 2RS
25	Vertical roller rod
26	Vertical roller
27	NILOS ring 32010 XAV
28	Bearing 32010 X
29	Eccentric bush
30	Bearing 32009 X
31	NILOS ring 32009 X
32	GUK nut M 45 x 1,5
35	
36	Counter vice interchangeable plate
37	Counter vice
38	Vice guide nut
39	Vice screw guard
40	Vice cylinder plate
41	Vice cylinder
42	Vice flywheel
43	Vice screw
44	Vice
45	Handwheel
46	Vice jaw
47	Roller support
48	Bearing NKI 20/16


49	Roller
50	Antiburr jaw
51	Counterservice jaw
60	Front protection
61	Rear protection
REFERENCE N°	DESCRIPTION
FEED CARRIAGE UNIT	
100	Microswitch
101	Microswitch support
102	Bushing
103	Ring
104	Roller support
105	Bearing NKI 16/32
106	Roller
107	feed carriage
108	Carriage counterservice guide nut
109	Plate
110	Carriage counterservice cylinder
111	Carriage counterservice
112	Carriage counterservice jaw
113	Carriage vice jaw
114	
115	
116	Handwheel
117	Protection gibs
118	
119	Carriage vice guide nut
120	Carriage vice screw
121	Carriage vice cylinder
122	Material end microswitch protection
123	Microswitch
124	Material end bushing
125	Carriage vice flywheel
126	Carriage vice cylinder plate
127	Material feed cylinder
128	Carriage guide gibs
129	Carriage vice
REFERENCE N°	DESCRIPTION
MEASUREMENT UNIT	
131	Front fastening
132	Magnetic rod
133	Guide bloc
134	Magnetic sensor
135	Support




REFERENCE N°	DESCRIPTION
SAW FRAME UNIT	
200	Adjustable blade guide block
201	Coupling
202	Fixed blade guide plate
203	Movable blade guide plate
204	Short eccentric pin
205	Bearing 608 2RS
206	Long eccentric pin
207	Blade guard on adjustable block
208	Blade guide adjustable rod
209	Handgrip with STZ switch
210	
211	Saw frame guard l.h. hinge
212	Saw frame guard
213	Fixed block l.h. blade guard
214	Saw frame r.h. hinge
215	Safety microswitch
216	
217	
218	
219	
220	
221	GUK M 30x1.5 ring nut
222	Nilos 32006 XAV ring
223	Bearing 32006
224	Transmission flywheel
225	Transmission flywheel spacer ring
226	Guard closing clip
227	Blade tightening gib
228	Blade tension cylinder
229	Transmission flywheel pin
230	Cooling liquid cock
231	Union
232	Coupling
233	Cooling distributor
234	Coupling
235	Coupling
236	Flywheel saw frame
237	Adjustable rod block bracket
238	Motor flywheel washer
239	Motor flywheel
240	Bearing 6208 2RS
241	Key
242	Reduction unit
243	Key
244	Key
245	Three-phase motor
246	Motor flywheel shaft
247	Washer
248	Spring coupling blade
249	Saw frame spring
250	Saw frame return spring bushing


REFERENCE N°	DESCRIPTION
251	Hinge pin
252	
253	Blade guide fixed rod
254	Blade cleaning brush
255	Bearing 626 2RS
256	Blade cleaning brush support
257	Brush return ring
258	Coupling
259	Fixed blade guide block
260	Additional protection
261	Fixed blade guide plate
262	Long eccentric pin
263	Bearing 608 2RS
264	Movable blade guide plate
265	Short eccentric pin
266	
267	
268	Spring
269	
270	
271	Blade tension handwheel
272	Bearing AX 2542+CP
273	Quick blade tension lever
274	Lever support
275	Protection
276	Pressure gauge
277	Pressure switch
REFERENCE N°	DESCRIPTION
SAW FRAME MOVEMENT CYLINDER UNIT	
300	Cylinder connect Bracket
301	Fork
302	Pin
303	Ring seeger Ø 20
304	
305	
306	
307	
308	Saw frame cylinder
309	
314	Bracket
320	Linear potentiometer
321	Guard
322	Bracket
323	Plate
324	Guard

BEDFRAME UNIT







SAW FRAME UNIT



SAW FRAME MOVEMENT CYLINDER UNIT




MEASUREMENT UNIT



I I. Hydrauliek en elektra tekeningen


ELECTRIC WIRING KEY

- 451 Fuse carrier cartridge
- 452 KM1 Remote control switch
- 453 KM2 Remote control switch
- 454 FR1 Thermal relay
- 456 FR2 Thermal relay
- 457 FR3 Thermal relay
- 458 KM3 remote control switch
- 459 TC1 transformer
- 460
- 461 KL Remote controlo switch
- 462 INVERTER (OPTIONAL)
- 463 INVERTER FILTER (OPTIONAL)



CONTROL PANEL KEY

- 401 Electronic programming instrument
- 405 Saw frame lowering adjustment
- 406 Main switch
- 407
- 408 Emergency push-button
- 409 Line push button



HYDRAULIC UNIT KEY

- 501 Hydraulic unit motor
- 502 Saw frame up stroke Speed regulator
- 503 Carriage feed speed adjustment
- 504 Running pressure gauge

