







MODEL	PART	DESCRIPTION	ARTIKELNR.
TLZ200V	1	BODY FRAME	674205729
TLZ200V	1(2)		674205731
TLZ200V	1A	PLATE	674205733
TLZ200V	2	SPRING AXIS	674205735
TLZ200V	3	SPRING	674205737
TLZ200V	4	32004 BEARING	674205739
TLZ200V	5	AXIS	674205741
TLZ200V	6	NUT	674205743
TLZ200V	7	WASHER	674205745
TLZ200V	8	FIXED BLADE GUIDE PLATEE	674205747
TLZ200V	8(1)	CHIP FENCE	674205749
TLZ200V	8(2)	SCREW	674205751
TLZ200V	11	BUSHING	674205753
TLZ200V	12	BEARING	674205755
TLZ200V	13	BEARING	674205757
TLZ200V	14	BIAS AXIS	674205759
TLZ200V	15	NUT	674205761
TLZ200V	16	WASHER	674205763
TLZ200V	17	ARM	674205765
TLZ200V	18	PIN	674205767
TLZ200V	18(1)	BEARING	674205769
TLZ200V	19	WASHER	674205771
TLZ200V	20	WASHER	674205773
TLZ200V	21	BEARING	674205775
TLZ200V	22	BEARING	674205777
TLZ200V	23	BIAS AXIS	674205779
TLZ200V	24	L. BLADE GUARD	674205781
TLZ200V	25	BOLT	674205783
TLZ200V	26	SCREW	674205785
TLZ200V	27	HANDLE SHELF	674205787
TLZ200V	28	HANDLE	674205789
TLZ200V	29	HANDLE WHEEL	674205791
TLZ200V	30	WASHER	674205793
TLZ200V	31	SCREW	674205795
TLZ200V	32	SCREW	674205797
TLZ200V	33	WASHER	674205799
TLZ200V	34	BEARING	674205801
TLZ200V	35	BLADE SHEET SHAFT	674205803
TLZ200V	36	WASHER	674205805
TLZ200V	37	BLOCK	674205807
TLZ200V	38	BLOCK BLADE TENSION	674205809
TLZ200V	39	RETURN FLYWHEEL	674205811
TLZ200V	40	SAW BLADE	674205813
TLZ200V	41	MOTOR FLYWHEEL	674205815

TLZ200V	42	SCREW	674205817
TLZ200V	43	BODY COVER	674205819
TLZ200V	44	NUT	674205821
TLZ200V	45	COVER	674205823
TLZ200V	46	BUSHING	674205825
TLZ200V	47	32004 BEARING	674205827
TLZ200V	48	SCREW	674205829
TLZ200V	49	WASHER	674205831
TLZ200V	50	MITER PLATE	674205833
TLZ200V	51	NUT	674205835
TLZ200V	52	WASHER	674205837
TLZ200V	53	SCREW	674205839
TLZ200V	54	NUT	674205841
TLZ200V	55	PLATE	674205843
TLZ200V	56	BOLT	674205845
TLZ200V	57	WASHER	674205847
TLZ200V	58	SCREW	674205849
TLZ200V	59	SCALE	674205851
TLZ200V	60	SCREW	674205853
TLZ200V	60(1)	WASHER	674205855
TLZ200V	61	BUSHING	674205857
TLZ200V	62	WASHER	674205859
TLZ200V	63	SCREW	674205861
TLZ200V	64N	BASE	674205863
TLZ200V	64N*1	RUBBER PAD	674205865
TLZ200V	64N*2	BASE PLATE	674205867
TLZ200V	64N*3	HANDLE ROD	674205869
TLZ200V	64N*4	SCREW	674205871
TLZ200V	65N	SCREW	674205873
TLZ200V	66N	FENCE BASE	674205875
TLZ200V	67N	LOCKING SEAT	674205877
TLZ200V	68N	WASHER	674205879
TLZ200V	69N	SCREW	674205881
TLZ200V	70N	ACME SCREW	674205883
TLZ200V	71N	KNOB	674205885
TLZ200V	72N	HANDLEROD	674205887
TLZ200V	73N	SHAFT BUSHING	674205889
TLZ200V	74N	BUSHING	674205891
TLZ200V	75N	SCREW	674205893
TLZ200V	76N	WISE	674205895
TLZ200V	77N	SCREW	674205897
TLZ200V	78N	WISE PLATE	674205899

TLZ200V	79N	SCREW	674205901
TLZ200V	80	NUT	674205903
TLZ200V	81	ROD STOCK STOP	674205905
TLZ200V	82	BOLT	674205907
TLZ200V	83	SCREW	674205909
TLZ200V	84	STOP BRAKET	674205911
TLZ200V	M1	SCREW	674205913
TLZ200V	M2	SPRING WASHER	674205915
TLZ200V	M3	BEARING	674205917
TLZ200V	M4	C-RING	674205919
TLZ200V	M5	GEAR	674205921
TLZ200V	M6	KEY	674205923
TLZ200V	M7	GEAR SHAFT	674205925
TLZ200V	M8	GEAR BOX	674205927
TLZ200V	M9	BEARING	674205929
TLZ200V	M10	OIL SEAL	674205931
TLZ200V	M11	GEAR	674205933
TLZ200V	M12	UP COVER	674205935
TLZ200V	M13	SCREW 4X45MM	674205937
TLZ200V	M14	NUT	674205939
TLZ200V	M15	FAN	674205941
TLZ200V	M16	SCREW	674205943
TLZ200V	M17	ELECTRICAL BOARD	674205945
TLZ200V	M18	OIL SEAL	674205947
TLZ200V	M19	MOTOR	674205949
TLZ200V	M19A	MOTOR SHAFT	674205951
TLZ200V	M20	SWITCH	674205953
TLZ200V	M21	DOWN COVER	674205955
TLZ200V	M22	PLUG	674205957
TLZ200V	M23	HANDEL WIRE	674205959
TLZ200V	M24	MAIN SHAFT	674205961
TLZ200V	M25	KEY	674205963
TLZ200V	M26	BEARING	674205965
TLZ200V	M27	PLASTIC COVER	674205967