


LIST OF SPARE PARTS ZIP 290 SO

BEDPLATE ASSEMBLY


REF.NR.DESCRPTION	CODE	PRICE ITL.	REF.NR.DESCRPTION	CODE	PRICE ITL.
002 Arm locking lever.....	AG280027		010 Arm for 0° - 45°	AGC40056	
004 Bedplate	E30A0001		011 Arm for 0° - 60°	AGC40120	
005 Spring attachment	AF750024		012 Pump	88140020	
006 Filter	AF750107		013 Cooling liquid tap	88600000	
007 Nilos ring 32007XAV	86005005		014 Rubber ring coupling ...	69501000	
008 Bearing 32007 X	84320025		015 Roller	49001003	
009 Bushing	E20A0010		016 Roller holding arm	E20A0004	

STRAIGHT VICE ASSEMBLY



REF.NR.	DESCRIPTION	CODE	PRICE ITL.	REF.NR.	DESCRIPTION	CODE	PRICE ITL.
101	Straight countervise	AGC40066		109	Bar stop push rod	AFC40109	
102	Straight vice	AGC40076		110	Scale	AHB80026	
104	Locking bush	AFB80012		111	Anti-burr jaw	AGC40068	
105	Rotation pin	AFC40060		112	Countervise jaw	E 20B0031	
106	O-Ring 3081	86002004		113	Vice jaw	E 20B0032	
107	Bar stop rod	AFB80024		114	Pneumatic vice cylinder	78100044	
108	Bar stop	AG660047		115	Vice handwheel	44116418	
				116	Vice cylinder	78100057	
				117	Vice screw	AFC90201	


SAW FRAME ASSEMBLY



REF.NR.	DESCRIPTION	CODE
201	Saw-frame	AHC40011
202	Spring attachment.....	AFC40131
203	Spring	E20C0068
204	Hinge pin	AFC40057
205	Ring nut GUK 35	81700035
206	Motor cover	53500112
207	Motor fan	53500128
208	Washer	D80C0083
209	Motor 3ph.....	74322050
210	Reduction unit 3ph.....	76200001
211		
212	Motor shaft	E20C1062
213	Key 8 x 7 x 50	82502082
214	Key 8 x 7 x 25	82502082
215	Bearing 6208-2RS	84113062
216	Two-way distributor	AFC40052
217	Mobile rod lock.dowel 60° AFC40051	
218	Mobile rod lock.dowel 45° AFC40051	
219	Handle M12 x 60	46112000
220	Blade tension slide gib. AFC40033	
221	Return flywheel slide.... AFC40035	
222	Blade tension slide..... AGC40032	
223	Blade tension threaded-rod	AFC40034
224	Belleville washer	82505101

RIF.NR.	DESCRIPTION	CODE
225	Blade tens. handwheel. 47200000	
226	Bladeguide head mov.rod E20C0064	
227	Handgrip with STZ..... 44600001	
228	Saw-frame mov.lever.... AFA40127	
229	Blade-guide rod guard. E20C0070	
230	Return flywheel	AGC40031
231	Nilos ring 32006XAV 86005005	
232	Bearing 32006 X	84320017
233	Ring nut GUK 30	81700030
234	Knob..... 44114512	
235	Blade left-hand guard .. E20C0069	
236	Flywheel guard	AFC40013
237	Motor flywheel washer. D80C0083	
238	Motor flywheel	AGC40021
239	Guard microswitch	72212000
240	Motor flywheel guard.... AFC40017	
241	Blade right-hand guard AFC40047	
242	Bl.-guide head fixed rod E20C0063	
243	Blade add.protection AFA40048	
244	Bl.-guide fixed head E20C0065	
245	Rubber holder coupling 69501000	
247	Bearing 608-2RS	84113010
248	Bearing 626-2RS	84113005
249	Bl.-guide mobile head.. E20C0066	
250	Micro holding plate	E30E0202
251	Blade tension micro 72212000	

SAW FRAME CYLINDER ASSEMBLY



REF.NR.	DESCRIPTION	CODE
---------	-------------	------


300	Dowel	AGC80221
301	Coupling fork	AF880082
302	Pin on fork	AF880080
303	Hydraulic cylinder for man/aut device	78100066
303a	Hydraulic cylinder std. ...	78100056
304	Lower adjustable stop....	AF88D085
305	Knob.....	44101213
306	Upper plate	AFB40089

REF.NR.	DESCRIPTION	CODE
---------	-------------	------

307	Upper adjustable stop..	AF88F085
308	Microswitch.....	72212000
309	Stop bar	AFC90222
310	Cylinder attachment	AGC80220
311	Cylinder guard	AFC90225
312	Cylinder articulation	AFC80176
313	Screw TCEI M 10	81110110
314	Micros.holding plate	AF88C085
322	Rod supporting block ...	AFB40085


ELECTRIC WIRING KEY

- 450 TC transformer
- 451 Auxiliary contact
- 452 KM1 remote control switch
- 453 KM2 remote control switch
- 454 KT Timer
- 455 KA1 auxiliary relay
- 456 KA2 auxiliary relay
- 457 KA3 auxiliary relay
- 458 KA4 auxiliary relay
- 459 Fuse holder
- 460 FRI temperature relay



CONTROL PANEL KEY

- 401 Main switch
- 402 Start push button
- 403 Speed switch
- 404 Saw frame selector
- 405 Cycle start push-button
- 406 Emergency push-button
- 407 Saw frame lowering adjustment



HYDRAULIC UNIT KEY

- 501 Vice hydraulic solenoid valve
- 502 Saw frame hydraulic solenoid valve
- 503 Hydraulic unit oil level
- 504 Pressure switch
- 505 Hydraulic unit motor
- 506 Oil filler cap

