


LIST OF SPARE PARTS ZIP 290.



REF.NR.	DESCRIPTION	CODE
---------	-------------	------

001	Pedestal	E 20A0001
002	Arm locking lever.....	AG280027
003	Locking bush.....	AFB80012
004	Bedplate	E 20A0002
005	Spring attachment.....	AF750024
006	Filter	AF750107
007	Nilos ring 32007XAV	86005005
008	Bearing 32007 X	84320025
009	Bushing	E 20A0010

REF.NR.	DESCRIPTION	CODE
---------	-------------	------



010	Arm for 0°- 45°	AGC40056
011	Arm for 0°- 60°	AGC40120
012	Pump	88140020
013	Cooling liquid tap	88600000
014	Rubber ring coupling ...	69501000
015	Roller	49001003
016	Roller holding arm	E 20A0004
017	Locking lever guard	E 20A0003



ELECTRIC COMPONENTS MOD ECO 290.

KEY

105	Auxiliary relay	72300000
106	Remote control switch	73401001
107	Fuse holder	73142005
108	Transformer	73327011
110	Cover gasket	D80E 0306
111	Cover	included part. 116



KEY

113	Reset button	70101000
114	Speed switch	70221018
115	Emergency button	70101000
116	Electric box	D80E 0305

410

411

412

413

414

415

416



KEY

410	Auxiliary relay	72300000
411	Remote-control switch	73401001
412	Fuse holder	73142005
413	Transformer	73327012
414	Terminal board	68303012
415	Cover gasket	ANC 40205
416	Cover	AFC 40203


418

421

417

419


420



KEY


417	Main switch	70201001
418	Reset button	70101000
419	Speed switch	70201050
420	Emergency button	70101000
421	Electric box	AFC 41201

HYDRAULIC BRAKE ASSEMBLY



REF.NR.	DESCRIPTION	CODE
---------	-------------	------


301	Cylinder articulation	AF750022
302	Brake cylinder	78100045
303	Brake cylinder spacer ..	AFC40132
304	Compensating tank	53400209



REF.NR.	DESCRIPTION	CODE
201	Saw-frame	AHC40011
202	Spring attachment.....	AFC40131
203	Spring	E20C0068
204	Hinge pin	AFC40057
205	Ring nut GUK 35	81700035
206	Motor cover.....	53500112
207	Motor fan	53500128
208	Washer.....	D80C0083
209	Motor 3ph.....	74322090
210	Reduction unit 3ph	76003001
211		
212	Motor shaft	E20C1062
213	Key 8 x 7 x 50	82502082
214	Key 8 x 7 x 25	82502082
215	Bearing 6208-2RS	84113062
216	Two-way distributor	AFC40052
217	Mobile rod lock.dowel 60°	AFC40051
218	Mobile rod lock.dowel 45°	AFC40051
219	Handle M12 x 60	46112000
220	Blade tension slide gib.	AFC40033
221	Return flywheel slide	AFC40035
222	Blade slide	AGC40032
223	Blade slide threaded-rod	AFC40034
224	Belleville washer	82505101

RIF.NR.	DESCRIPTION	CODE
225	Blade tens. handwheel.	47200000
226	Bladeguide head mov.rod	E20C0064
227	Handgrip with STZ.....	44600001
228	Saw-frame mov.lever....	AFA40127
229	Blade-guide rod guard.	E20C0070
230	Return flywheel	AGC40031
231	Nilos ring 32006XAV	86005005
232	Bearing 32006 X	84320017
233	Ring nut GUK 30	81700030
234	Knob.....	44114512
235	Blad left-hand guard....	E20C0069
236	Flywheel guard.....	AFC40013
237	Motor flywheel washer.	D80C0083
238	Motor flywheel	AGC40021
239	Guard microswitch	72212000
240	Motor flywheel guard....	AFC40017
241	Blade right-hand guard	AFC40047
242	Bl.-guide head fixed rod	E20C0063
243	Blade add.protection	AFA40048
244	Bl.-guide fixed head	E20C0065
245	Rubber holder coupling	69501000
246		
247	Bearing 608-2RS	84113010
248	Bearing 626-2RS	84113005
249	Bl.-guide mobile head..	E20C0066

INCLINED VICE ASSEMBLY




REF.NR.	DESCRIPTION	CODE
---------	-------------	------

PRICE I.T.L.

151	45° counter vice	AGC40086
152	45° vice	AGC40096
153	Jaw support	AGC40099
154	Eccentric pin	AFC40100
155	Vice closing plate	AFC40102
156	Locking lever	AGC40101
157	45° vice jaw	E20B0042
158	45° counter vice jaw	E20B0041
159	45° vice screw	AFC40098

STRAIGHT VICE ASSEMBLY



REF.NR.	DESCRIPTION	CODE
---------	-------------	------

101	Straight countervice	AGC40066
102	Straight vice	AGC40076
103	Spring	AFB80035
104	Straight vice screw	AFC40078
105	Rotation pin	AFC40060
106	O-Ring 3081	86002004
107	Bar stop rod	AFB80024
108	Bar stop	AG660047
109	Bar stop push rod	AFC40109
110	Scale	AHB80026

PRICE I.T.L.

REF.NR.	DESCRIPTION	CODE
---------	-------------	------

111	Anti-burr jaw	AGC40068
112	Counter vice jaw	E20B0031
113	Vice jaw	E20B0032
114	Vice lever bushing	AFB80032
115	Quick lock vice lever	AGB80031
116	Fifth wheel AX 3047+	
117	CP 3047 bearing	84500001
118	Quick lock lever washer	AFB80033
119	Vice handwheel	44116418
120	Handwheel washer	AFC40083

PRICE I.T.L.