


**REX 60A III**

**Parts List**




**Rex Industries Ltd.**

# REX 60A III (Base)



No.	Part No.	Part Name	Set	
1	4 0 4 1	Base	1	
2	4 0 4 2	Base cover	1	
3		Washer	2	
4		Spring washer	2	
5		Round head machine screw (M 5×8)	2	
6	4 0 4 7	Strainer	1	4048 Strainer guided
7		Round head machine screw (M 6×10)	1	
8	4 0 4 4	Tank upper cover	1	
9	4 0 8 3	Upper cover strainer	1	
10	4 0 8 5	Chip receiver	1	
11	4 0 4 3	Oil drip tray	1	
12		Nut (M 6)	2	
13		Toothed lock washer	4	
14		Hex head screw (M 6×15)	2	
15	4 0 4 5	Bottom cover	1	
16		Round head machine screw (M 5×8)	3	
17		Drain plug (PT 1/4")	1	
18		Suction tube bush	1	
19		Hex head screw	4	
20		Spring washer	4	
21		Socket head cap screw (M 8×65)	4	
22		Hex socket set screw (M 8×10)	2	
23				
24				
25				

# REX 60A III (Motor)




No.	Part No.	Part Name	Set
1	4 0 3 2	Condenser motor 600W(100V, 200V)	1
2	4 0 6 1	Motor V pulley (2.½)	1
		Motor V pulley (3½)	1
3		Hex socket set screw (M 8 × 12)	1
4		Spring washer (10mm)	4
5		Hex head screw (M10 × 20)	4
6		Earth cord	1
7	4 0 0 1	Motor holder	1
8	4 0 0 2	Rubber gasket	1
9	4 0 4 6	Motor cover	1
10		Washer (5 mm)	2
11		Spring washer (5 mm)	2
12		Round head machine screw (M 5 × 16)	2
13		Spring washer (8 mm)	4
14		Socket head cap screw (M 8 × 25)	2
		Socket head cap screw (M 8 × 30)	2
15		Socket head cap screw (M 8 × 65)	1
16		Nut (M 8)	2
17		Starter condenser	1
18		Drive condenser	1
19		Washer (5 mm)	2
20		Round head machine screw (M 5 × 8)	2
21		Drive belt (A-22)	2
22			
23			
24			
25			




No.	Part No.	Part Name	Set	
1	4 0 0 0	Head stock	1	
2	4 0 0 8	Flange	1	024J
3	4 0 0 6	Main shaft	1	
4	4 0 0 7	Main shaft gear	1	
5	7 2 0 7	Front bearing	1	
6	4 0 0 5	Rear bearing	1	
7	4 0 3 8	Thrust ring	1	
	4 0 1 1	Rear chuck		
8		Rear receptacle	1	
9		Rear scroll	1	
10		Rear chuck jaw	1	
11		Rear chuck cover	1	
12		Round head machin screw (M 5 × 15)	6	
13		Spring washer (5 mm)	6	
14		Nut (M 5)	6	
15		Roll pin (6 × 12)	3	
16	4 0 0 9	Hand wheel	1	
	1 2 3 5	Chuck		
17		Chuck body	1	
18		Chuck scroll	1	
19		Chuck jaw	3	
20		Chuck jaw insert	3	
21		Spring retainer	3	
22		Spring	3	
23		Set screw	6	
24		Hex socket cap screw (M 7 × 54)	6	
25		Hex socket cap screw (M 6 × 50)	6	
26		Spring washer (6 mm)	6	
27		Roll pin (4 × 10)	4	
28	4 0 3 0	Gear stop pin	2	
29	1 4 0 2	Switch	1	
		Switch "Kango R10"	1	
30	A 1 9 8	Switch packing	1	
31		Oval head machine screw (M 4 × 16)	2	
32	7 0 2 1	Cord bush	1	
33	1 4 1 0	Cabtyre cord	1	
34		Binder	1	
35		Toothed lock washer	2	
36		Round head machine screw (M 4 × 10)	2	
37	4 0 3 9	Name plate	1	
38		Rivet (6 × 5)	6	
39	4 0 3 1	Change position plate	1	
40	4 0 2 4	Stop washer	1	
41		Stop screw (M 5 × 16)	1	
42		Lubrication fitting	2	
43		Hex socket set screw (M 8 × 10)	3	
44	4 0 4 0	Hose guide	1	
45	4 0 8 6	Hose band	1	
46		Spring washer (6 mm)	1	
47		Round head machine screw (M 6 × 10)	1	
48	4 0 0 3	Rear cover	1	
49				
50				
51				
52				
53				
54				

# REX 60A III (Die head)




No.	Part No.	Part Name	Set	
1	7 7 2 3	Die head body ( $\frac{1}{2} \sim \frac{3}{4}$ )	1	
	7 7 2 1	Die head body (1 ~ 2)	1	
2	7 6 8 3	Die head ring ( $\frac{1}{2} \sim \frac{3}{4}$ )	1	
	7 6 4 6	Die head ring (1 ~ 2)	1	
3		Socket head cap screw (M 4 × 12)	16	
4	7 7 2 7	Cam plate ( $\frac{1}{2} \sim \frac{3}{4}$ )	1	
	7 7 2 5	Cam plate (1 ~ 2)	1	
5	7 7 4 7	Size plate ( $\frac{1}{2} \sim \frac{3}{4}$ )	1	
	7 7 4 5	Size plate (1 ~ 2)	1	
6		Rivet	8	
7	7 6 9 2	Die head position pin	6	
8	7 6 9 3	Size adjustment knob	6	
9		Socket head cap screw (M 6 × 10)	6	
10	7 7 2 9	Retaining ring ( $\frac{1}{2} \sim \frac{3}{4}$ )	1	
	2 3 5 2	Retaining ring (1 ~ 2)	1	
11		Socket head cap screw (M 6 × 16)	8	
12	7 7 4 1	Opening block ( $\frac{1}{2} \sim 2$ )	2	
13	7 6 9 0	Size setting lever	2	
14	7 7 4 3	Size adjust plate	4	
15	7 7 9 0	Knoch pin	2	
16		Spring	2	
17	7 7 4 2	Retaining pin	2	
18	7 6 9 8	Spring	2	
19	7 7 3 5	Spring guide	2	
20	7 6 9 7	Spring	2	
21	7 7 3 3	Auto - open lever ( $\frac{1}{2} \sim \frac{3}{4}$ )	1	
	7 7 3 1	Auto - open lever (1 ~ 2)	1	
		NPT Auto-open lever (1 ~ 2)	1	
22	7 7 5 3	Guide plate ( $\frac{1}{2} \sim \frac{3}{4}$ )	1	7756 (Europa)
	7 7 3 6	Guide plate (1 ~ 2)	1	7757 (Europa)
23	7 7 3 7	Guide plate pin L	2	
24		Roll pin (4 × 12)	2	
25	7 6 9 6	Lever spring	2	
26	7 7 3 9	Cam plate spring	2	
27	7 7 3 4	Lever pin	2	
28	7 6 9 4	Stop pin	2	
29		Spring	2	
30	7 6 9 5	Knob	2	
31		Roll pin (3 × 12)	1	
32	7 7 5 8	Steel stop plate	1	
33		Rivet	1	
34	7 7 4 9	Adjust plate (1 ~ 2)	1	
	7 7 5 1	Adjust plate ( $\frac{1}{2} \sim \frac{3}{4}$ )	1	
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				

# REX 60A III (Carriage)




No.	Part No.	Part Name	Set
1	4 0 5 0	Carriage	1
2	4 0 5 1	Carriage support bar A	1
3	4 0 5 2	Carriage support bar B	1
4	4 0 5 9	Carriage support collar (25)	1
		Carriage support collar (15)	1
5	4 0 5 4	Carriage feed handle	1
6	A 5 1 5	Carriage feed gear	1
7		Wavy washer	1
8	4 0 5 6	Stop collar tensile	1
9		Round head machine screw (M 5 × 30)	1
10	7 0 2 2	Elbow	1
11	4 0 5 8	Oil pipe connector	1
12	4 0 5 7	Oil pipe	1
13	1 0 3 5	Nipple	1
14		Steel ball	2
15		Spring	1
16		Hex socket set screw (M10 × 10)	1
17		Hex socket set screw (M 6 × 20)	1
18		Nut (M 6)	1
19		Spring	1
20		Push nut	1
21			
22			
23			
24			
25			

# REX 60A III (Cutter, Reamer)



No.	Part No.	Part Name	Set
1	4 0 6 6	Cutter frame	1
2	4 0 7 1	Cutter handle	1
3	4 0 6 7	Cutter guide	1
4	5 0 7 6	Cutter wheel	1
5	2 4 7 1	Cutter pin S	1
6	9 0 2 7	Guide pin	1
7	4 0 7 0	Spring	1
8	5 0 7 4	Cutter roller	2
9	5 0 7 9	Cutter pin L	2
10	4 0 6 9	Cutter arm	1
11	1 0 7 6	Cutter arm pin	1
12	4 0 7 2	Stop pin	1
13		Cutter pin	3
14	4 0 7 5	Reamer holder	1
15	4 0 7 6	Reamer shaft	1
16	1 0 9 3	Reamer cone	1
17		Roll pin (8 × 36)	1
18		Roll pin (8 × 45)	1
19		Roll pin (5 × 12)	2
20		Spring	2
21		Steel ball	1
22	1 0 9 6	Reamer pin	1
23			
24			
25			

# REX 60A III (Gear)



No.	Part No.	Part Name	Set	
1	4 0 1 2	A shaft	1	
2	4 0 4 9	Bearing (6204LL)	3	
3		Snap ring (STW20)	1	
4	4 0 6 2	V Pulley	1	
	4 0 6 4	V Pulley	1	
5		Snap ring (STW18)	1	
6		Hex socket set screw (M 8 × 20)	1	
7	4 0 8 1	Key (5 × 5 × 20)	1	
8	H 2 7 2	Bearing (6202LL)	3	
9		Wavy washer (BWW6202)	2	
10	4 0 1 3	B shaft	1	
11	4 0 1 6	Clutch gear S	1	4035 Clutch metal S
12	4 0 3 7	B shaft collar S	1	
13		Snap ring (STW23)	1	
14	4 0 1 7	Clutch	1	
15	4 0 1 5	Clutch gear L	1	4034 Clutch metal L
16	4 0 8 4	B shaft collar M	1	
17	4 0 3 6	B shaft collar L	1	
18		Snap ring (STW15)	1	
19	4 0 1 4	C shaft	1	
20		Snap ring (STW36)	2	
21	4 0 1 8	C shaft gear	1	
22	4 0 8 0	Key (10 × 8 × 14)	1	
23		Snap ring (STW20)	1	
24		Wavy washer (BWW6204)	1	
25	4 0 2 5	Gear pump	1	
		Reversible gear pump	1	
26		Hex socket cap screw (M 6 × 35)	1	
27		Hex socket cap screw (M 6 × 20)	1	
28		Oil suction tube	1	
29		Oil feed tube	1	
30		Oil band	2	
31	1 0 3 5	Nipple	2	
32	4 0 2 0	Speed change handle	1	
33	4 0 2 1	Speed change cover	1	
34		Steel ball	2	
35	4 0 3 3	Spring	2	
36		Roll pin (5 × 30)	1	
37		Socket head cap screw (M 6 × 16)	2	
38	4 0 2 2	Rubber washer	1	
39		Snap ring (STW15)	1	
40	4 0 2 3	Fork lever	1	
41	4 0 1 9	Gear shift fork	1	
42				
43				
44				
45				
46				
47				
48				
49				
50				
51				
52				
53				
54				
55				